

BERM REPAIR KIT INSTRUCTIONS

This patch kit is designed to repair holes, punctures and small tears up to 4" in length. Before repairing more extensive damage please give us a call at 1 (800) 247-3846.

WHAT YOU NEED TO KNOW

REPAIR TAPE INSTRUCTIONS

Note:

**Repair Tape is meant for temporary repairs.
Glued patches should be used for permanent repairs.**

1. Clean and dry the damaged area.
2. Scuff the area around the tear with sandpaper, both on the inside and the outside of the berm.
3. Clean the scuffed areas with the included alcohol pads.
4. Cut a piece of tape that will cover the hole by at least 1" on all sides. (Round each corner.)
5. Peel off the paper backing.
6. Press the tape firmly onto the berm, covering both the inside and the outside of the tear.



GLUE REPAIR INSTRUCTIONS

PREPARATION

1. Clean and dry the damaged area.
2. Thoroughly clean the area to be patched using the included alcohol pads.
3. Cut out a rounded patch, using the provided fabric, that overlaps the hole by at least 2" on all sides.
4. Scuff the surface of the area to be patched and the smoother side of the patch itself with the included sandpaper.
5. Wipe off the scuffed areas with an alcohol pad.

GLUE

1. Apply a thin, even layer of glue to the scuffed areas on both the berm and the patch and allow it to dry.
2. After the glue is dry, apply a second coat of glue both surfaces and let them dry until the glue is tacky.
3. Apply the patch to the berm in a rolling motion.
4. Use a roller or rounded edged putty knife to apply pressure to the whole patch and to push out any bubbles.

USE

Let the glue cure for 24 hours.

Need a custom size, color or design? Call 1 (800) 247-3846.

