

QUICK SNAP BERM INSTRUCTIONS

Quick Snap Berms provide reliable secondary containment. Their preinstalled snap-together stays fit on the outside of the berm, freeing up all of the interior space for equipment. And, like all of our berms they're constructed of durable, chemical resistant fabric that you can depend on.

WHAT YOU NEED TO KNOW

SITE PREP

1. Clear a deployment area of debris that might damage the berm.

DEPLOYMENT

1. Unfold the berm.
2. Snap together the preinstalled stays.
3. Lift the berm walls.
4. Drive stakes through the grommets in the staking patches. *(if needed)*

REPAIR

1. Clean the area to be patched using denatured alcohol.

Patches should always be applied to the inside of the berm.

2. Cut out the patch material, rounding the corners so that they don't peel up.
3. Peel the paper backing from the adhesive patch.
4. Center the patch over the hole.
5. Apply the patch in a rolling motion.
6. Rub out any bubbles.



AFTER USE

1. Drain the berm according to environmental regulations.
2. Unsnap the stays.
3. Fold the berm.
4. Store in a dry place, protected from the sun and rodents.

RECOMMENDED PRODUCTS



Mini Spill Kit



Diversion Tube



Spill Monkey Filter

Need a custom size, color or design? Call 1 (800) 247-3846.

