

QUICK SNAP FOAM BERM INSTRUCTIONS

AIRE Environmental Quick Snap Foam Berms provide quick, drive-through secondary containment. Their side walls are supported by our popular Quick Snap stays and its self-standing foam wall ends crush down when driven over, but regain their shape soon afterward so that you don't have to waste time lowering and raising them.

WHAT YOU NEED TO KNOW

SITE PREP

1. Clear a deployment area of debris that might damage the berm.

DEPLOYMENT

1. Unfold the berm.
2. Snap together the preinstalled stays.
3. Lift the berm walls.
4. Drive stakes through the grommets in the staking patches. *(if needed)*

REPAIR

Patches should always be applied to the inside of the berm.

1. Clean the area to be patched using denatured alcohol.
2. Cut out a piece of patch material 1" larger than the damaged area, rounding the corners so that they don't peel up.
3. Peel the paper backing from the patch.
4. Center the patch over the hole.
5. Apply the patch in a rolling motion.
6. Rub out any bubbles.



AFTER USE

1. Drain the berm according to environmental regulations.
2. Unsnap the stays.
3. Fold the berm.
4. Store in a dry place, protected from the sun and rodents.

RECOMMENDED PRODUCTS



Mini Spill Kit



Diversion Tube



Spill Monkey Filter

Need a custom size, color or design? Call 1 (800) 247-3846.

