

# REPAIR KIT INSTRUCTIONS (Waste Water Bladder)

This patch kit is designed to repair holes, punctures and small tears up to 1” in diameter. Before repairing more extensive damage please give us a call at 1 (800) 247-3846.

## WHAT YOU NEED TO KNOW

### PREPARATION

1. Drain and dry the Waste Water Bladder.
2. Thoroughly clean the area to be patched using the included alcohol pads.
3. Using the provided fabric, cut out a rounded patch that overlaps the hole by at least 2” on all sides.
4. Scuff the surface of the area to be patched and the smoother side of the patch itself with the included sandpaper.
5. Wipe off both of the scuffed areas with an alcohol pad.



### GLUE (HH-66)

1. Apply a thin even layer of glue to the scuffed areas and allow it to dry completely.
2. After the glue is dry, apply a second coat of glue and let it dry until it is tacky.
3. Apply the patch to the bladder in a rolling motion.
4. Use a roller or rounded edged putty knife to apply pressure to the whole patch and to push out any bubbles.

### USE

Give the glue 24 hours to cure before filling the tank with water.

*\*Consult local water management for cleaning recommendations.*

## RECOMMENDED PRODUCTS

**Diversion Tube**



**L-Stay Berm**



**Spill Kits**



**Duck Pond Berm**



Need a custom size, color or design? Call 1 (800) 247-3846.

