

WELLHEAD BERM INSTRUCTIONS

The AIRE Environmental Wellhead Berm protects the area directly around wellheads from contamination. Its split wall enables the user to fit it entirely around wellheads and the hood provides a reverse funnel into the berm. Each Wellhead Berm is also fitted with a slip resistant surface to protect workers. Wellhead Berms are extremely tough and ready to take on harsh oil field conditions.

WHAT YOU NEED TO KNOW

SITE PREP

1. Clear any debris from the deployment area.

DEPLOYMENT

1. After removing the berm from its packaging, unfold it close to the wellhead.
2. Use the berm's split wall to fit it around the wellhead.
3. Snap the bridge panel over the split wall.
4. Fit the hood around the wellhead and secure the seam using the hook and loop strips.
5. Check the hood's center height to make sure that the perimeter snaps will reach the snaps on the berm.
6. Use the ratchet strap to secure the hood to the wellhead.
7. Snap the hood to the berm.



RECOMMENDED PRODUCTS

Mini Spill Kit



Roughneck Berm



Stay Wall Berms



Duck Pond Berm



Need a custom size, color or design? Call 1 (800) 247-3846.

